



# SET UP INSTRUCTIONS

- Product Launches
- Schools and Sports Clubs
- Hospitality Tents
- Government Services
- Charities
- Motor Sports
- Field Days
- Market Stalls
- Golf Events




Best with assistance of another person

Grasp the lower "V" at centre Truss Bar.  
Lift and pull the frame half way out.



Place Canopy top on partially opened framework. Align to each corner.



Attach Velcro securely at each corner.  
Continue to expand frame completely out.  
Be careful not to pinch hands as you step backwards slowly



Now that Frame is fully expanded. Push Sliding leg Brackets upwards until Ring Pull Pin locks into position on each leg.



Lift each leg until the Ring Pull snaps into the first hole.



For height adjustment, place your foot on each leg footpad and slowly extend each leg to desired height.

**7** Never leave your Canopy unattended in inclement weather. Always ensure the Canopy is securely anchored to the Ground.

REMEMBER - THE WEATHER CAN CHANGE UNEXPECTEDLY